




# Instructions




**1. Snap the two halves of the base plate cover apart.**



**2. Fit the two parts around the post and snap together.**



**3. To prevent lifting, use exterior silicone caulking to secure the cover to the plate.**



**4. Clean annually using soap and water.**