




Instructions




1. Snap the two halves of the base plate cover apart.



2. Fit the two parts around the post and snap together.



3. To prevent lifting, use exterior silicone caulking to secure the cover to the plate.



4. Clean annually using soap and water.